

Installation Instructions for 2014 MyLink iNAV-LINK-GM404 for Impala, Sierra, & Silverado

- 1. Remove Screen**
- 2. Remove LVDS plug, and data plug from the screen**
- 3. Reroute new LVDS cable to screen, plug OEM into new unit**
- 4. Cut back shield tape on factory 10 pin connector**
- 5. Make the following wire connections: Conect the 8 lead PLUG from the interface to the factory radio harness as follows:**
 - A. Red - To 12-Volt Red on Car Harness**
 - B. Yellow - ACCESS, DO NOT CONNECT**
 - C. Black - To Ground on car harness (PIN 10)**
 - D. Green - Do not connect**
 - E. White - Tap into PIN 3 on car harness - Green Wire**
 - G. White - Tap into PIN 5 on car harness - Green-Blue Wire**
- 6. Cut PIN 8 on Car Harness - Green White cable - connect to the interface wire harness as follows:**
 - A. Connect Wire 7 White to Car side of Car Harness**
 - B. Connect Wire 8 White - To Radio Side of Car Harness**
- 7. Mount GPS antenna above and behind screen area.**
- 8. Set DIP switch settings on the interface as follows:**
 - A. Settings for Vehicles that have a Factory Camera:**
 - Set Switches 1, 5, and 8 in ON Position (DOWN)**
 - Set Switches 2, 3, 4, 6, 7 in the OFF Position (UP)**
 - B. Settings for Vehicles using an Aftermarket Camera:**
 - Set Switches 1, 4, and 5 in the ON Position**
 - Set Switches 2, 3, 6, 7, and 8 in the OFF Position**

When finished installing the unity, PRESS and HOLD the screen on the left side for 3 SECONDS to switch to navigation. For a First Startup & Configuration guide for the Navigation software, please visit the SUPPORT page at www.icar-link.com/support.aspx.