

# Universal Media Interface

## Quick Phone Pairing Guide

To pair a phone to the HU select the CD6 button That will enter the Pairing menu as shown on the screen below




Press and hold SEEK+ to enter the Bluetooth pairing sub menu. Different pairing options are available as example "Pair new device"



Scroll with SEEK+ or SEEK- to select the right action from the available choices to either pair new device or delete all and pair a device



To enter Phone menu press  button until the screen changes to phone menu




When the phone is paired field strength bars are shown on the phone menu screen. The phone book downloads in approximately a minute, depending on how large the phonebook is



Select the messaging button to see the dialled, missed, received calls menu or to write instant message



Selecting any of the buttons above including the phone book displays the phone numbers as shown below



To write a message to another phone subscriber select the messaging button and type the message



To access the phone book select the phone book button. To call a number from the phone book select the name and press the dial button



Shortcut to delete and pair command is available from the phone menu by typing \*\*3 and then press the call button




Shortcut to pair new phone command is available from the phone menu by typing \*\*7 and then press the call button



# Land Rover USB Media Interface

## Quick CD6 Menu Guide

Power the head unit and selected Audio Video tab from the Welcome LR Head unit menu as shown below



If no media is attached there will be no selection in the audio CDC menu. The audio may be on Pause by default as shown below



Press CD6 button to switch to the functions available in the More menu. The pairing menu is the default top level menu when in CD6 mode



To enter the Pairing menu press and hold the SEEK+ button. Then the screen changes showing pairing menu in mid section



Scroll the submenus with SEEK+ and SEEK- buttons. To select a sub function press and hold SEEK+, to exit SEEK-, to exit SEEK-



The next high level menu after pairing is the settings menu. You can enter the settings by press and hold SEEK+



The screen changes showing the settings in mid screen. First sub menu of the settings menu is the media player software version



To go to the next sub menu press SEEK+. The second sub menu of the settings menu is the Bluetooth software version



Scroll with SEEK+ to the next sub menu. The third menu is privacy mode. This menu allows turning the text to speech on and off



To turn the speech ON during incoming call and outgoing call scroll with SEEK+ to the Speech ON menu and press and hold SEEK+



To turn the speech OFF during incoming call and outgoing call scroll with SEEK+ to the Speech OFF menu and press and hold SEEK+



# Universal Media Interface

## Quick CD6 Menu Guide (Continue)

If already in CD6 (More) menu and screen shows settings menu, scroll with SEEK+/SEEK- between the service menus of the media player



The fourth menu is Bluetooth audio menu. This menu sets the device in direct audio streaming control mode



Enter the menu by pressing and hold SEEK+. In this mode the screen shows -SEEK<>SEEK+ that allows the player to be controlled remotely



The fifth menu down is the iPod player mode menu. The screen of the iPod can be unlocked using those functions



To lock the iPod screen select the player lock and press and hold SEEK+



To unlock the iPod screen select the player unlock and press and hold SEEK+



When the iPod is unlocked cannot be controlled anymore from the HU screen and the screen shows iPod audio streaming



When iPod not locked, select CD1 to play a playlist. Find a playlist using SEEK+ or SEEK- buttons and select it by pressing and hold SEEK+



Select CD2 to play the songs by Artist. Find an artist using SEEK+ or SEEK- buttons and select it by pressing and hold SEEK+



Select CD3 to play the songs by Album. Find an album using SEEK+ or SEEK- buttons and select it by pressing and hold SEEK+



Select CD4 to play the songs by Genre. Find genre using SEEK+ or SEEK- buttons and select it by pressing and hold SEEK+

